

HOLMAN

Battery Powered Hose Reel

with Li-ION Technology



www.holmanindustries.com.au

User Guide

Contents

Overview	2
Specifications	2
Components	3
Safety Warnings	4
Storage	5
Disposal of the Battery	5
Cleaning	5
Installation	6
Mounting the Bracket	6
Moving the Stopper	7
Using the Hose Reel	8
Battery LED Status	8
Charging	9
Charging the Battery	9
Spare Parts	10
Warranty	11

Overview

Specifications

- ✓ Battery: 3 Li-Ion batteries
- ✓ Battery capacity: 2.0Ah with 11V
- ✓ Battery charging: approx. 4-5 hours
- ✓ Battery charger: mains voltage 100–240 V/ 50–60 Hz, rated output current 700 mA

Overview

Components

- | | |
|-----------------------------|--------------------------|
| 1. Protective housing | 7. Universal tap adaptor |
| 2. Li-ion battery | 8. Wall bracket |
| 3. 12.6v battery charger | 9. Tap-to-reel hose |
| 4. 30m multi-purpose hose | 10. 4× 8mm screws |
| 5. Multi function spray gun | 11. 4× 11.7 wall plugs |
| 6. Snap-on hose connectors | |



Model no: 3130H

Overview

Safety Warnings

- ⚠ The battery charger may not be used to charge any other batteries, other than the supplied battery.**
- ⚠ Only use the supplied battery in the hose reel. Unauthorised batteries risk exploding.**
- ⚠ Over voltage can destroy the battery and the charger. Observe correct mains voltage.**
- ⚠ Do not bridge contacts of the battery charger or the battery, with metal parts.**
- ⚠ After intensive use, let the battery cool before charging.**
- ⚠ Disconnect the charging plug before storing the battery charger.**
- ⚠ Due to the danger of physical injury, the battery may not be used as an energy source for other appliances.**
- ⚠ Never charge batteries near acids and highly flammable materials.**
- ⚠ Protect the battery against heat and fire. Do not place on radiators or expose to intense sunlight for long periods. Only use and charge the battery in ambient temperature between 5°C and 45°C.**
- ⚠ The mains charging cable must be inspected regularly for signs of damage and aging (brittleness) and may only be used in perfect condition.**
- ⚠ Do not open the hose reel housing or the battery.**

Overview

Storage

- i** In regions prone to frost, stow the hose housing and the battery in a frost-proof place in an upright position.
- i** Do not store the battery in conditions over 45°C or under direct sunlight. Remove the battery from the hose housing and charge it before storing it separately.
- i** Do not store the battery in places with static electricity.

Disposal of the Battery

- ⚠ The battery is composed of lithium-ion which must not be disposed with normal household waste at the end of its life.**
- i** Please check with your local council to see where you can dispose of the battery properly.



Cleaning

- i** The hose housing is maintenance-free and must not be cleaned with water or solvents. If necessary, clean the contacts of the battery with a dry cloth.

Need help? Just ask!

The Holman website has a host of additional information on features. Head to support.holmanindustries.com.au for more tips, tricks and support content.

If you still need help, feel free to email our friendly Customer Service team at support@holmanindustries.com.au or call at [08 9416 9999](tel:0894169999).



SCAN FOR MORE INFO

Installation

Mounting the Bracket

1. Remove the wall bracket from the housing unit by unscrewing the safety screw [a] from the bottom of the bracket



- i** The supplied wall plugs are suitable for cement walls (plaster up to 1cm). For other wall types, specific wall plugs for that type of wall must be used (not supplied)

2. Mark holes using the wall bracket [b]



3. Drill into the wall with a 10mm drill bit [c] and push in the wall plugs




4. Screw in the wall bracket [d] with the four screws [e]



5. Mount the hose housing [f] onto the wall bracket [g]

Installation


Mounting the Bracket



6. Re-secure the hose housing with the supplied safety screw [h]



7. Connect the tap-to-reel hose [i] to your garden tap [j]




Moving the Stopper

- i** If required, the stopper can be moved along the length of the hose

- ⚠** **Remove the battery before moving the stopper**

8. Loosen the two screws on the stopper [a] with a screwdriver



9. Holding the hose, shift the stopper and re-tighten with the two screws

Operation

Using the Hose Reel

UNWINDING: Pull out hose to desired length

ROLLING UP: Holding the end of the hose, walk back to the hose housing and hold the **RUN** button down [a] until the hose has been rolled up to the desired length.



PROTECTIVE FUNCTION:

If the hose is blocked or completely rolled up, the motor automatically switches off

- When the battery is fully charged, the hose can be rolled up to 35 times

Battery LED Status

The charging level of the battery is displayed briefly every time the **RUN** button is pressed.

Charge LED [a] blue x3:
Battery is fully charged

Charge LED [a] yellow x2:
Battery is half-charged

Charge LED [a] red x1:
Battery low, needs charging

Charge LED [a] red - flashing:
Battery dead, needs charging

Power LED [b]: Indicates if hose reel is powered on or off. If this LED is red, it may indicate a battery fault



Charging

Charging the Battery

⚠ The battery must be fully charged prior to first use

1. Press the release button [a] and remove the battery



2. Insert the battery charger into a mains socket
3. Insert the plug of the charging cable [b] into the bottom of the battery [c]



4. Once charged, slide the battery back into the hose housing until it snaps in

- The lithium-ion battery can be charged at every charging level and charging can be interrupted at any time without damaging the battery

Charging control lamp [d] is red: Battery is charged

Charging control lamp [d] is green: Battery is fully charged



⚠ Never expose the battery charger to moisture or wetness

Spare Parts

Hose Reel Bracket

Includes 4 x wall plugs and
4 x hexagonal coach bolts



(3130BP)

Battery Charger

Battery charger for the
Lithium ION battery



(3130BC)

10 of 12

Li-ION Battery

Replacement Lithium ION battery



(3130BAT)

Stopper Ball

Replacement stopper ball



(1120BS)

To order spare parts
please call our
customer service
team on
1300 716 188, or order online:
www.holmanindustries.com.au



Warranty

2 Year Replacement Guarantee - Housing and Battery



Holman Industries offers a 2
year replacement guarantee
with this product.

In Australia our goods come with
guarantees that cannot be excluded
under the Australian Consumer
Law. You are entitled to a replacement or refund
for a major failure and compensation for any other
reasonably foreseeable loss or damage. You are
also entitled to have the goods repaired or replaced
if the goods fail to be of acceptable quality and
the failure does not amount to a major failure.

As well as your statutory rights referred to above
and any other rights and remedies you have under
any other laws relating to your Holman product,
we also provide you with a Holman guarantee.

Holman Industries guarantees this product against
defects caused by faulty workmanship and materials
for 2 years domestic use from the date of purchase.

During this guarantee period Holman Industries
will replace any defective product. Packaging and
instructions may not be replaced unless faulty.

In the event of a product being replaced during
the guarantee period, the guarantee on the
replacement product will expire 2 years from the
purchase date of the original product, not
2 years from the date of replacement.

To the extent permitted by law, this Holman
Replacement Guarantee excludes liability for
consequential loss or any other loss or damage
caused to property of persons arising from any
cause whatsoever. It also excludes defects caused
by the product not being used in accordance with
instructions, accidental damage, misuse, or being
tampered with by unauthorised persons, excludes
normal wear and tear and does not cover the cost
of claiming under the warranty or transporting the
goods to and from the place of purchase.

6 Year Replacement Guarantee - Hose



Holman offers a 6 year replacement
guarantee with this product.

In Australia our goods come with
guarantees that cannot be excluded
under the Australian Consumer Law.
You are entitled to a replacement
or refund for a major failure and compensation for
any other reasonably foreseeable loss or damage.
You are also entitled to have the goods repaired or
replaced if the goods fail to be of acceptable quality
and the failure does not amount to a major failure.

As well as your statutory rights referred to above
and any other rights and remedies you have under
any other laws relating to your Holman product,
we also provide you with a Holman guarantee.

Holman guarantees this product against defects
caused by faulty workmanship and materials for
6 years domestic use from the date of purchase.

During this guarantee period Holman will
replace any defective product. Packaging and
instructions may not be replaced unless faulty.

In the event of a product being replaced during
the guarantee period, the guarantee on the
replacement product will expire 6 years from the
purchase date of the original product, not
6 years from the date of replacement.

To the extent permitted by law, this Holman
Replacement Guarantee excludes liability for
consequential loss or any other loss or damage
caused to property of persons arising from any
cause whatsoever. It also excludes defects caused
by the product not being used in accordance with
instructions, accidental damage, misuse, or being
tampered with by unauthorised persons, excludes
normal wear and tear and does not cover the cost
of claiming under the warranty or transporting the
goods to and from the place of purchase.

Should you suspect your product may be defective and need some clarification or advice please contact us
directly: 1300 716 188 or support@holmanindustries.com.au, 11 Walters Drive, Osborne Park 6017 WA

If you are certain your product is defective and is covered by the terms of this warranty, you will need to present
your defective product and your purchase receipt as proof of purchase to the place you purchased it from, where
the retailer will replace the product for you on our behalf.



**Thanks for being a
#SMARTGARDENER**



We really appreciate having you as a customer, and would like to say thank you for choosing us.

We recommend registering your new product on our website. This will ensure we have a copy of your purchase and activate an extended warranty. Keep up to date to with relevant product information and special offers available through our newsletter.

www.holmanindustries.com.au/product-registration/



HOLMAN

For the #SMARTGARDENER   

Copyright © 2021 Holman Industries